

K2500


Performance Guide

KURZWEIL

Music Systems

©1996 All rights reserved. Kurzweil is a product line of Young Chang Co.; V. A. S. T. is a registered trademark, and Kurzweil, K2500, and K2000 are trademarks of Young Chang Co. All other products and brand names are trademarks or registered trademarks of their respective companies. Product features and specifications are subject to change without notice.

Part Number: 910251 Rev. F



The lightning flash with the arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

IMPORTANT SAFETY & INSTALLATION INSTRUCTIONS

INSTRUCTIONS PERTAINING TO THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

WARNING - When using electric products, basic precautions should always be followed, including the following:

1. Read all of the Safety and Installation Instructions and Explanation of Graphic Symbols before using the product.
2. This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a power supply cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

DANGER - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Do not modify the plug provided with the the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician. Do not use an adaptor which defeats the function of the equipment-grounding conductor. If you are in doubt as to whether the product is properly grounded, check with a qualified serviceman or electrician.

3. **WARNING** - This product is equipped with an AC input voltage selector. The voltage selector has been factory set for the mains supply voltage in the country where this unit was sold. Changing the voltage selector may require the use of a different power supply cord or attachment plug, or both. To reduce the risk of fire or electric shock, refer servicing to qualified maintenance personnel.

4. Do not use this product near water - for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.

5. This product should only be used with a stand or cart that is recommended by the manufacturer.

6. This product, either alone or in combination with an amplifier and speakers or headphones, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

7. The product should be located so that its location or position does not interfere with its proper ventilation.

8. The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.

9. The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.

10. This product may be equipped with a polarized line plug (one blade wider than the other). This is a safety feature. If you are unable to insert the plug into the outlet, contact an electrician to replace your obsolete outlet. Do not defeat the safety purpose of the plug.

11. The power supply cord of the product should be unplugged from the outlet when left unused for a long period of time. When unplugging the power supply cord, do not pull on the cord, but grasp it by the plug.

12. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

13. The product should be serviced by qualified service personnel when:

- A. The power supply cord or the plug has been damaged; or
- B. Objects have fallen, or liquid has been spilled into the product; or
- C. The product has been exposed to rain; or
- D. The product does not appear to be operating normally or exhibits a marked change in performance; or
- E. The product has been dropped, or the enclosure damaged.

14. Do not attempt to to service the product beyond that described in the user maintenance instructions. All other servicing should be referred to qualified service personnel.

15. **WARNING** - Do not place objects on the product's power supply cord, or place the product in a position where anyone could trip over, walk on, or roll anything over cords of any type. Do not allow the product to rest on or be installed over cords of any type. Improper installations of this type create the possibility of a fire hazard and/or personal injury.

RADIO AND TELEVISION INTERFERENCE

Warning: Changes or modifications to this instrument not expressly approved by Young Chang could void your authority to operate the instrument.

Important: When connecting this product to accessories and/or other equipment use only high quality shielded cables.

Note: This instrument has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This instrument generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this instrument does cause harmful interference to radio or television reception, which can be determined by turning the instrument off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the instrument and the receiver.
- Connect the instrument into an outlet on a circuit other than the one to which the receiver is connected.
- If necessary consult your dealer or an experienced radio/television technician for additional suggestions.

NOTICE

This apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

AVIS

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la class B prescrites dans le Reglement sur le brouillage radioelectrique edicte par le ministere des Communications du Canada.

SAVE THESE INSTRUCTIONS

Table of Contents

Young Chang Distributors	x
Introduction	1-1
Welcome!	1-1
For K2500R Owners	1-1
Overview of the K2500	1-2
What is VAST?	1-3
How to use this manual	1-4
Startup	2-1
Basic Startup Checklist:	2-1
Startup—the Details	2-2
Before You Start...	2-2
Battery Installation	2-2
Connecting the Power Cable (Line Cord)	2-3
Connecting the Audio Cables.	2-3
Connecting MIDI	2-3
Connecting SCSI	2-4
Switching On the Power	2-4
Playing the Presets	2-4
Programs	2-4
Setups	2-5
Quick Access	2-6
Performance Controls	2-7
K2500 Boot Loader	2-8
Starting the Boot Loader	2-8
Boot-loader Main Menu	2-8
Install System / Install Objects	2-8
Run System	2-9
Hard Reset	2-10
Run Diags	2-10
Fixed Diags	2-10
Software Upgrades	2-10
User Interface Basics	3-1
Mode Selection	3-1
Data Entry	3-4
Intuitive Data Entry	3-6
Search Function	3-7
The Panel Play Feature (Rack Models)	3-7
The Mixdown and MIDI Faders Pages (Keyboard Models Only)	3-8
The Operating Modes	4-1
What the Modes Are	4-1
Selecting Modes	4-1
Using the Modes	4-3

Editing Conventions	5-1
Introduction to Editing	5-1
Object Type and ID	5-2
Saving and Naming	5-2
Deleting Objects	5-4
Memory Banks	5-5
Special Button Functions	5-6
Program Mode and the Program Editor	6-1
K2500 Program Structure	6-2
The Program Mode Page	6-2
What are these programs in parentheses?	6-3
Control Setup	6-3
The Soft Buttons in Program Mode	6-4
Using the Program Editor	6-4
Algorithm Basics	6-5
Common DSP Control Parameters	6-6
Program Editor—Algorithm (ALG) Page	6-10
Program Editor—LAYER Page	6-11
Program Editor—KEYMAP Page	6-14
Program Editor—PITCH Page	6-17
Program Editor—F1–F3 Pages	6-18
Program Editor—F4 AMP Page	6-19
Program Editor—OUTPUT Page	6-21
Program Editor—EFFECT Page	6-24
Program Editor—COMMON Page	6-25
Program Editor—Amplitude Envelope (AMPENV) Page	6-28
Program Editor—Envelopes 2 and 3	6-31
Program Editor—Envelope Control (ENVCTL) Page	6-32
Program Editor—LFO Page	6-34
Program Editor—ASR Page	6-36
Program Editor—FUN Page	6-37
Program Editor—VTRIG Page	6-38
Function Soft Buttons	6-39
Setup Mode and the Setup Editor	7-1
Setup Mode	7-1
K2500 Rack Models Only	7-2
The Control Setup	7-2
The Setup Editor	7-4
The Channel/Program (CH/PROG) Page	7-4
The Key/Velocity (KEY/VEL) Page	7-9
The Pan/Volume (PAN/VOL) Page	7-16
The BEND Page	7-17
Controllers	7-19
The MIDI Control Source List	7-21
Continuous Controller Parameters	7-24

Destination (Dest)	7-24
Scale	7-24
Offset (Add)	7-24
Curve (Curv)	7-24
Entry (Ent) and Exit Values	7-25
The SLIDER and SLID/2 Pages	7-25
The Continuous Control Pedal (CPEDAL) Page	7-26
The RIBBON Page	7-27
The WHEEL Page	7-28
The Pressure (PRESS) Page	7-29
Switch Controller Parameters	7-30
Switch Type (SwType)	7-30
Destination	7-30
On Value	7-30
Off Value	7-31
Entry (Ent) and Exit States	7-31
The Footswitch (FOOTSW) Page	7-31
The SWITCH Page	7-32
The COMMON Page	7-32
The Arpeggiator (ARPEG) Page	7-33
The Ribbon Configuration (RIBCFG) Page	7-39
The Utility Soft Buttons	7-41
Editing Hints and Suggestions	7-44
Do These Parameters Always Mean Something?	7-44
Do I Need All Those Pedals?	7-44
Multiple Controllers	7-44
Editing Programs	7-44
Quick Access Mode and the	
Quick Access Editor	8-1
Effects Mode and the Effects Editor	9-1
The Effects Mode Page	9-1
The Soft Buttons on the Effects mode Page	9-1
Effects Mode Parameters	9-2
Understanding FX Mode and FX Channel	9-2
Another Use for Effects Mode	9-5
The Effects Editor	9-6
Editing Effects	9-6
Configurations and Parameters	9-7
MIDI Mode	10-1
The Transmit (XMIT) Page	10-1
The Receive (RECV) Page	10-4
.....	10-6
The Channels Page	10-8
Parameter Locks	10-9
Program Change Formats	10-10

	Extended and Kurzweil Program Change Types	10-11
	The Soft Buttons in MIDI Mode	10-18
Master Mode	11-1
	The Master Mode Page	11-1
	The Soft Buttons in Master Mode	11-4
	Guitar/Wind Controller Mode	11-5
	Object Utilities	11-6
	Move	11-7
	Copy	11-8
	Name	11-9
	Delete	11-9
	Dump	11-10
	Accessing the Object Utilities from the Editor	11-10
Song Mode	12-1
	Getting Started with the Sequencer	12-1
	A Word about the Local Keyboard Channel	12-1
	Tutorial: Recording a song	12-2
	MAIN Page	12-11
	Soft Buttons on the MAIN Page	12-15
	Save this song? Dialog	12-16
	Save New song? Dialog	12-17
	Erase Track Dialog	12-17
	MISC Page	12-18
	Soft Buttons on the MISC Page	12-22
	MIX Page	12-23
	Soft Buttons on the MIX Page	12-24
	The Edit Song Pages	12-25
	Edit Song: COMMON Page	12-25
	Parameters used with the Arrangement Feature	12-26
	Soft Buttons on the Edit Song: COMMON Page	12-27
	Edit Song: EVENT Page	12-28
	Soft Buttons on the Edit Song: EVENT Page	12-29
	Edit Song: TRACK Page	12-31
	Common Parameters for Edit Song: Track Functions	12-32
	Region / Criteria Window Parameters	12-32
	Soft Buttons on the Edit Song: Track Page	12-33
	Edit Song: Track Functions – Erase	12-34
	Edit Song: Track Functions – Copy	12-34
	Edit Song: Track Functions – Bounce	12-35
	Edit Song: Track Functions – Insert	12-35
	Edit Song: Track Functions – Delete	12-36
	Edit Song: Track Functions – Quantize	12-36
	Edit Song: Track Functions – Reference Quantize	12-37
	Edit Song: Track Functions – Shift	12-38
	Edit Song: Track Functions – Transpose	12-39

Edit Song: Track Functions – Change	12-39
Edit Song: Track Functions – Thin	12-40
Edit Song: Track Functions – Remap	12-41
Edit Song: Track Functions – Grab	12-41
Edit Song: STEP Page	12-43
Recording with the STEP editor	12-43
Soft Buttons on the Edit Song: STEP Page	12-45
Edit Song: ARRANGE Page	12-46
Triggering Steps from a Key	12-48
Soft Buttons on the Edit Song: ARRANGE Page	12-49
Selecting a Song for Playback	12-49
Effect Selection During Recording and Playback	12-50
Synchronizing Songs	12-50
Memory Limits	12-51
Loading Songs From Disk	12-51
Recording Multi-timbral Sequences via MIDI	12-52
Disk Mode	13-1
Disk Mode Page	13-1
File List Dialog	13-6
Creating Directories	13-11
Creating a Directory with NewDir	13-11
Creating a Directory with the Save and NewDir Soft Buttons	13-12
The Directory Selection Dialog	13-12
Disk Mode Functions	13-13
Loading Files	13-13
Loading Individual Objects	13-13
Shortcuts when Loading Objects	13-16
Loading Dependents of Selected Objects	13-17
Auditioning Samples from a Disk File	13-17
Loading Objects from Floppy Disk Files	13-18
Load Function Dialog	13-18
Bank Status Indicator	13-18
Loading Methods	13-18
Multiple Selection of Files to Load	13-21
Aborting a Multiple File Load	13-21
More Load Function Enhancements	13-22
Saving Files	13-22
Saving Individual Objects	13-24
Shortcuts when Saving Objects	13-24
Auditioning Objects in RAM	13-25
Saving Dependent Objects	13-26
The Name Table	13-27
Working with Relink-by-Name	13-28
Not Loading the Name Table	13-31
Relink-by-Name Processing Time	13-31

The Multiple Object Selector Page	13-32
Macros	13-38
The Macro Page	13-38
Macro Modes	13-39
The Macro Table	13-40
How to Make a Macro File	13-41
Macro Entries	13-45
Using the Bank and Mode Fields	13-46
Viewing the Object List for a Macro Entry	13-46
Unspecified Disk Drive ID	13-47
The Library Disk	13-47
Loading Selected Entries from a Macro File	13-49
Editing Macros	13-50
Macro Insert	13-53
Saving and Loading a Macro Table in a .KRZ file	13-54
Aborting a Macro Load	13-54
Remote Macro Load	13-55
Disk Utilities	13-56
Find Files	13-56
List	13-58
Free	13-58
Moving Files Between Directories	13-59
Renaming Files	13-61
Deleting Files and Directories	13-61
Backup and Copy Functions	13-62
File Copy	13-64
Creating a Startup File	13-65
Deleting Banks in a Startup File	13-65
MS-DOS File System Compatibility	13-66
File Name Compatibility	13-66
Importing and Exporting Data using Standard File Formats	13-67
AIFF and AIFF-C Files	13-67
WAVE Files	13-68
Standard MIDI Files (MIDI Type 0 and Type 1 Files)	13-68
DSP Functions	14-1
Introduction to Algorithm Programming	14-1
Additional Parameters	14-3
Filters	14-5
How to read the graphs	14-6
Equalization (EQ)	14-22
Pitch / Amplitude / Panner	14-31
Mixers	14-34
Waveforms	14-35
Added Waveforms	14-38
Non-linear Functions	14-38

Waveforms Combined with Non-linear Functions	14-48
Mixers with Non-linear Inputs	14-50
Hard Sync Functions	14-51
Sampling and Sample Editing	15-1
Setting Up For Sampling	15-1
Cables and Input Jacks	15-1
Entering The Sampler - Two Different Ways	15-2
Sampling Analog Signals	15-2
Recording Samples	15-6
Sampling the K2500's Output	15-8
Using the Sampler to Create Overdubs	15-8
Sampling Digital Signals	15-10
Using the Digital Outputs	15-11
Editing Samples	15-12
Crossfade and Volume Adjust Curves	15-33
Reading Samples	15-34
The Keymap Editor	15-36
Building a Keymap	15-41
Using the Analog Inputs to Trigger Samples	15-42
FUNS	16-1
The Mechanics of Control Sources	16-1
Programming the FUNs	16-2
The FUN Equations	16-3
The List of Equations	16-4
Warp Equations	16-10
Sawtooth LFOs	16-13
Chaotic LFOs	16-13
Diode Equations	16-14
The Order of Evaluation for FUNs	16-16
Other Editors	17-1
The Intonation Table Editor	17-1
The Velocity Map Editor	17-3
Using the Velocity Map Editor	17-3
The Pressure Map Editor	17-6
Audio Outputs	18-1
Audio Configurations	18-1
Using the MIX Outputs	18-1
Using the Separate Outputs	18-2
Output Groups and MIDI Channels	18-4
Programming Examples	19-1
Example 1 - Trumpet with Delayed Vibrato and Velocity-triggered Fall-offs	19-1
Example 2 - Lowpass Filter, Envelopes	19-4
Example 3 - Sample and Hold; Using a FUN	19-6
Example 4 - SHAPER and PANNER	19-7
Example 5 - Building a Drum Program; Using the Keymap Editor	19-9

Young Chang Distributors

Contact the nearest Young Chang office listed below to locate your local Young Chang/ Kurzweil representative.

Young Chang America, Inc.

13336 Alondra Blvd.
Cerritos, CA 90703-2245
Tel: (310) 926-3200
Fax: (310) 404-0748

Young Chang Co.

Kang Nam P.O.Box 998
Seoul, Korea
Tel: 011-82-2-3451-3500
Fax: 011-82-2-3451-3599

Young Chang Akki Europe GmbH

Industriering 45
D-41751 Viersen
Germany
Tel: 011-49-2162-4491
Fax: 011-49-2162-41744

Young Chang Canada Corp.

395 Cochrane Drive
Markham, Ontario L3R 9R5
Tel: (905) 513-6240
Fax: (905) 513-9445